# ROCKYARD CARE INSTRUCTIONS

It requires little maintenance but for best long lasting results.



## BASIC CLEANING:

- Wipe the surface with a soft cloth to remove dust.
- Clean the surface using lukewarm water and a soft, dust-free cloth. Avoid cream surface cleaners.
- Dry with a soft, dry cloth or allow to air dry.
- Avoid cleaning tools with rough surfaces to prevent scratches.

### How to Avoid Scratches?

- Furniture finished with high gloss is sensitive to contact with shoes.
- Use coasters/mats to protect the surface from scratching.

### Caution:

- Hot items (above 50°C) such as mugs, cups, and plates can cause permanent dull spots on the surface. Always use coasters or heat-resistant pads for hot items.
- Keep out of direct sunlight and away from heat sources.

## REGULAR MAINTENANCE:

- Use pure beeswax furniture polish to maintain the product’s shine.

## SAFETY NOTE:

- Always lift the furniture when moving it to avoid damage or injury.
- Do not tilt the furniture. Ensure it is placed securely on the ground.
- Never stand, climb, or jump on the furniture.