
ANTI-TIP KIT INSTRUCTIONS

IMAGE	COMPONENT	QTY
	Brackets	2 Pieces
	Small Screws	2 Pieces
	Long Screws	2 Pieces
	Wire Strap	1 Pieces
	Rivet	2 Pieces
	Pin	2 Pieces

1. Using the short screws, attach one bracket to the rear of the furniture frame below the top surface.

2. Move the furniture into its final position to mark the wall location. Move the furniture away and attach the second bracket to the wall.

3. Attach the wall bracket using the long screws.

4. Move the furniture back into position. Secure the wire strap through both brackets using the supplied rivet and locking pin.

