


1




2



3



4



Richmond INTERIORS

ITEM 216148

A	B	C	D
 M8x734	 M8/14#	 ϕ 22x ϕ 10x1. 5	 14#
4PCS	4PCS	4PCS	1PC

PAPER MARBLE FINISH

Care & Maintenance Instructions

Clean spills immediately
Wipe up any spills right away to prevent staining. Be especially careful with acidic foods and drinks, as they can damage the surface.Clean spills immediately
Wipe up any spills right away to prevent staining or dulling of the glossy finish.

Protect from heat and stains
Always use placemats and coasters to shield the surface from food, beverages, and hot items.

Use gentle cleaning methods
Clean with a soft, lint-free cloth and lukewarm, soapy water to remove stains or stubborn dirt. Dry thoroughly after cleaning to prevent moisture damage.

Avoid abrasive products
Do not use abrasive or chemical-based cleaners, as they can damage the protective coating and make the surface more susceptible to future stains.

Indoor use only
This product is intended for indoor use. Outdoor exposure can lead to irreversible damage.

Handle with care
Avoid dragging or placing sharp or rough objects directly on the surface to prevent scratches or dull spots.

By following these simple care steps, your paper marble finish will preserve its refined look and smooth surface for years to come.

Richmond
INTERIORS

GLOSSY FINISH

Care & Maintenance Instructions

Protect from heat
High gloss finishes are not naturally heat resistant. Always use mats or coasters under hot dishes, mugs, or decorative objects to protect the surface from heat damage.

Clean spills immediately
Wipe up any spills right away to prevent staining or dulling of the glossy finish.

Use gentle cleaning methods
Clean with a soft, lint-free cloth and warm, soapy water to remove stains and stubborn dirt. Avoid using excessive water and dry the surface immediately after cleaning.

Avoid harsh chemicals
Do not use abrasive cleaners, ammonia-based products, or strong solvents, as these can damage the high gloss coating and reduce shine.

Prevent scratches
Avoid dragging objects across the surface. Use felt pads under accessories or décor items to maintain a smooth, flawless finish.

Indoor use only
This product is intended for indoor use. Outdoor exposure can lead to irreversible damage.

Dust regularly
Use a clean, soft microfiber cloth to remove dust and fingerprints, maintaining the mirror-like appearance.

Handle with care
High gloss surfaces can mark easily; avoid impact or pressure from heavy objects to prevent dents or cracks.

By following these simple care steps, your high gloss furniture will retain its elegant shine and flawless appearance for years to come.

Richmond INTERIORS