

MDF

Care & Maintenance Instructions

Clean spills immediately
MDF (Medium-Density Fiberboard) is durable but vulnerable to moisture. Wipe spills immediately with a soft cloth to prevent damage.

Avoid harsh chemicals
Do not use acidic or abrasive cleaners like bleach, ammonia, or acetone. Stick to mild, non-abrasive cleaning solutions.

Use soft materials
Clean with a soft microfiber cloth. For surface stains, use a damp cloth with mild soapy water, then dry immediately.

Avoid excess water and dry immediately
Never soak MDF, as water can cause swelling or warping. Always wipe dry after cleaning to prevent moisture absorption.

Protect from heat and moisture
Use coasters or heat-resistant mats under hot items. Avoid placing wet or damp objects directly on the surface, as MDF is highly susceptible to swelling and mold growth.

Dust regularly
Wipe with a soft, lint-free cloth to prevent dust buildup and scratches.

Seal periodically
MDF surfaces come pre-sealed. Depending on use, resealing by a professional is recommended.

Prevent heavy impact
Avoid dropping or dragging heavy objects across the surface to prevent dents or damage.

Indoor use only
This product is for indoor use. Outdoor exposure can cause damage.

Scratch sensitivity
Use placemats or tablecloths to protect against scratches. Avoid sharp or heavy items on the surface.

By following these simple steps, your MDF furniture will remain in excellent condition for years to come.

Richmond
INTERIORS