

Care & Maintenance Instructions

Clean with care
Use a soft cloth slightly moistened with warm, soapy water. Avoid abrasive tools. Dry with a soft dry cloth or let air dry.

Avoid harsh products
Do not use detergents with silicone or ammonia—these can dry out the wood and cause cracking. Opt for mild, non-detergent soap.

Natural stain removal
For tougher stains like sunscreen or mold, use a solution of white vinegar and water.

Protect from sunlight
Prolonged direct sunlight can damage the surface. A pigmented finishing oil is recommended for extra UV protection.

Use coasters and mats
Always use coasters or placemats to prevent scratches. For hot dishes or bowls, use heat-resistant pads.

By following these simple steps, your mango wood furniture will remain beautiful and durable for years.

Richmond
INTERIORS