

Hinge Adjustment Instruction



Required tools- Screw driver


Adjusting foot Instruction

①




If the right door tilts downward, you can turn the right front or left rear adjusting feet counterclockwise until the left and right door panels are on the same horizontal line

②



If the left door tilts downward, you can turn the left front or right rear adjusting feet counterclockwise until the left and right door panels are on the same horizontal line



The adjusting foot rotates counterclockwise, the screw is screwed out, and the height of the furniture increases



The adjusting foot rotates clockwise, the screw becomes shorter, the adjusting foot is tightened, and the height of the furniture becomes shorter